



VERTEC TPE BIOCOMPATIBILITY

Technical Datasheet

TEST METHOD

Cytotoxicity – ISO 10993-5, Biological evaluation – part 5: Tests for in vitro cytotoxicity.

TEST SUMMARY

The potential biological reactivity of a mammalian cell culture (mouse fibroblast L929) in response to exposure to the extract of the test article, Thermoplastic Elastomer (TPE), WFV FM71* film, was determined. The test article was extracted in Minimum Essential Medium (MEM) with 10% Fetal Bovine Serum (referred to as complete MEM) for 24 ± 2 hours at 37 ± 1 °C. Negative and positive controls were prepared similarly. The maintenance medium of L929 cells grown in 6-well plates was replaced with the 100% (neat) extracts in 3 replicates, and the cells were incubated for 48 ± 2 hours at 37 ± 1 °C. The biological reactivity of the cells following the exposure to the extracts was visually observed with a microscope, and graded on a scale of 0 to 4.

RESULT

There was no biological reactivity (Grade 0) of the cells exposed to the test article extract. The response obtained from the positive and negative control article extracts confirmed the suitability of the test system.

Based on the criteria of the protocol and the ISO 10993-5 guidelines, the test article meets the requirements of the test and is not considered to have a cytotoxic effect.

**WFV FM71 was selected as the worst case representation for Vertec Thermoplastic Elastomer family of products.*

GEL-PAK

31398 Huntwood Avenue, Hayward, CA 94544

Toll-Free 888-621-4147 **Phone** 510-576-2220 **Fax** 510-576-2282

Website www.gelpak.com

Division of

DELPHON